


TRK48A / TRK48B / TRK37A / TRK37B TREKKER OUTBACK - SIDE CASE



1	ZOBK37ALFM	OBK37AL assembled Bottom Shell silver, left side
	ZOBK37BLFM	OBK37BL assembled Bottom Shell black, left side
	ZOBK37ARFM	OBK37AR assembled Bottom Shell silver, right side
	ZOBK37BRFM	OBK37BR assembled Bottom Shell black, right side
	ZOBK48ALFM	OBK48AL assembled Bottom Shell silver, left side
	ZOBK48BLFM	OBK48BL assembled Bottom Shell black, left side
	ZOBK48ARFM	OBK48AR assembled Bottom Shell silver, right side
2	ZOBK37ALCM	OBK37AL assembled Top Shell silver, left side
	ZOBK37BLCM	OBK37BL assembled Top Shell black, left side
	ZOBK37ARCM	OBK37AR assembled Top Shell silver, right side
3	ZOBK37BRCM	OBK37BR assembled Top Shell black, right side
	ZOBK48ALCM	OBK48AL assembled Top Shell silver, left side
	ZOBK48BLCM	OBK48BL assembled Top Shell black, left side
	ZOBK48ARCM	OBK48AR assembled Top Shell silver, right side

4	Z4810SXMR	Rear fitting system, left side
	Z4810DXMR	Rear fitting system, right side
5	Z4830R	Aluminum release lever for Trekker Outback 37 lt
	Z4831R	Aluminum release lever for Trekker Outback 48 lt
6	Z4812R	Angular coverage
	Z115R	Stop bag opening yarn, 2 pcs.
7	SL101	Security Lock key, including bush and under lock platelets